GENERAL

ashrae cooling and heating load calculation manual 2nd edition

Published: September 19, 2026 | Index ID: #-

Introduction

When architects, engineers, and HVAC professionals design a building, one of the most critical tasks is to determine how much cooling and heating the space will require. Accurate load calculations ensure that the HVAC system is neither oversized nor undersized, which directly affects comfort, energy consumption, and operating costs. The **ASHRAE Cooling and Heating Load Calculation Manual 2nd Edition** is the industry's definitive guide for performing these calculations with precision. In this article, we'll explore the manual's evolution, its core principles, how to use it in practice, and why it remains indispensable for modern building design.

What Is the ASHRAE Manual?

ASHRAE, the American Society of Heating, Refrigerating, and Air Conditioning Engineers, publishes a series of technical handbooks that set the standard for HVAC design worldwide. The Cooling and Heating Load Calculation Manual is one of the most frequently referenced documents. The 2nd edition, released in 2010, updated the original 1995 edition to reflect advances in building materials, equipment efficiency, and regulatory requirements.

Key Differences from the 1st Edition

- Updated Code References – Incorporates the latest International Energy Conservation Code (IECC) and ASHRAE 90.1 requirements.
- Expanded Climate Data – Adds more detailed regional climate information, improving the accuracy of outdoor air calculations.
- Enhanced Software Compatibility – Provides guidelines for integrating calculations with popular HVAC design tools like Trane Trace, Carrier HAP, and EnergyPlus.
- Improved Load Calculation Methodology – Introduces a clearer step by step process for both cooling and heating loads, emphasizing the importance of ventilation and infiltration.

Why the 2nd Edition Is Still Relevant

Even though newer editions of ASHRAE handbooks exist, the 2nd edition remains in widespread use because:

- It strikes a balance between simplicity and depth, making it suitable for both novices and seasoned professionals.
- Its step by step approach is easily translatable into custom spreadsheets, which many firms still rely on.
- It contains a comprehensive set of tables and equations that cover a wide range of building types, from residential to commercial.

Getting Started: How to Use the Manual

Before diving into calculations, it's essential to understand the structure of the manual. It is organized into four main parts:

1. Introduction and Scope – Outlines the purpose, assumptions, and limitations.

2. Load Calculation Methodology – Provides the theoretical background and step by step procedures.
3. Tables and Appendices – Offers reference tables for equipment sizing, climate data, and heat transfer coefficients.
4. Case Studies – Demonstrates real-world applications.

Below is a concise guide to navigating each section.

Step 1: Define the Building Parameters

Start by gathering essential data:

- Building footprint and floor area
- Number of stories and ceiling height
- Orientation and window-to-wall ratio
- Insulation values (R numbers) for walls, roofs, and floors
- Occupancy load and internal heat gains (lighting, equipment, people)

Step 2: Select the Appropriate Climate Zone

The manual includes tables that correlate climate zones with design temperatures and humidity levels. Selecting the correct zone is critical because it determines the baseline for outdoor air temperature and dew point, which directly influence cooling and heating loads.

Step 3: Calculate the Cooling Load

1. Determine Solar Gains – Use the solar heat gain coefficient (SHGC) for windows and apply the manual's formulas for different orientations.
2. Compute Internal Gains – Sum up heat from occupants, lighting, equipment, and cooking appliances.
3. Account for Ventilation and Infiltration – Apply the manual's ventilation rate tables and infiltration coefficients.
4. Apply Loss/Gain Factors – Adjust for building envelope performance using the envelope heat transfer coefficients.
5. Sum All Components – The total cooling load is the sum of solar, internal, ventilation, and envelope gains.

Step 4: Calculate the Heating Load

1. Determine Solar Gains – Similar to cooling, but here solar gains reduce the heating load.
2. Compute Internal Losses – Account for heat generated by occupants, lighting, and equipment that is lost to the interior.
3. Ventilation and Infiltration – Use the same methodology as for cooling but consider the colder outdoor temperature.
4. Envelope Losses – Apply the heat loss coefficient for walls, roofs, and floors.
5. Sum All Components – The total heating load is the sum of all losses minus any solar gains.

Integrating the Manual with Modern Software

While the manual provides all the equations and tables needed for manual calculations, many professionals now use computer-aided design (CAD) and HVAC simulation tools. The 2nd edition's guidelines on software integration are particularly useful.

Popular Tools and How They Align with the Manual

- Carrier HAP – Offers a step by step load calculation wizard that mirrors the manual's methodology.
- Trane Trace 700 – Includes climate data and envelope analysis modules based on the manual's tables.
- EnergyPlus – A building energy simulation program that can be configured to follow the manual's assumptions.

When using these tools, always double check the input parameters against the manual's recommended values to avoid discrepancies.

Common Challenges and How to Overcome Them

Even with a solid reference like the 2nd edition, HVAC designers often encounter pitfalls. Below are some common issues and practical solutions.

1. Inaccurate Climate Data

Using outdated or incorrect climate data can skew load calculations. Always reference the latest climate tables provided in the manual, and cross verify with local meteorological sources.

2. Misinterpreting Solar Heat Gain Coefficients

SHGC values vary by window type, glazing, and orientation. The manual provides detailed tables, but designers sometimes overlook the importance of specifying the correct product. Verify window specifications with manufacturers or product data sheets.

3. Overlooking Ventilation Requirements

ASHRAE standards dictate minimum ventilation rates for indoor air quality. Failing to account for these rates can lead to under sized HVAC systems. The manual's ventilation tables should be consulted for each space type.

4. Ignoring Infiltration Losses

Infiltration can contribute significantly to heating and cooling loads, especially in older buildings. Use the manual's infiltration coefficient tables based on construction type and building age.

5. Inconsistent Unit Conversions

ASHRAE calculations often involve both SI and Imperial units. Ensure consistent unit usage throughout the calculation process to avoid errors.

Case Study: Designing a Small Office Building

Let's walk through a simplified example of applying the 2nd edition to a 5,000 square foot office building in a temperate climate zone.

Building Overview

- Single story, 10 /m x 5 /m floor plan
- Ceiling height: 3 /m
- Wall R value: 2.5 /m²·k/W
- Roof R value: 4.0 /m²·k/W
- Window to wall ratio: 20%
- Occupancy: 25 people (each 80 /W of internal heat)
- Lighting: 15 /W/m²

Cooling Load Calculation

1. Solar Gains – Using the manual's SHGC table for double pane windows, the solar heat gain per square meter of glazing is 0.5 /kW. For 1,000 /m² of glazing, solar gains = 500 /kW.
2. Internal Gains – Occupants: 25 × 80 /W = 2 /kW. Lighting: 5,000 /m² × 15 /W/m² = 75 /kW. Total internal = 77 /kW.
3. Ventilation – ASHRAE 62.1 requires 20 /L/s per person. For 25 people, ventilation = 500 /L/s. Using the manual's ventilation heat load formula, this equates to 30 /kW.

4. Envelope Losses – Calculated using the manual's heat transfer coefficient tables, envelope losses = 15 /kW.
5. Total Cooling Load – 500 /kW + 77 /kW + 30 /kW + 15 /kW = 622 /kW.

Heating Load Calculation

1. Solar Gains – Solar heat gains reduce the heating load. Assume 50% of the 500 /kW solar gains are available for heating, so 250 /kW.
2. Internal Losses – Occupants and lighting produce heat that is retained indoors, reducing heating load. The manual's internal heat loss calculation gives 60 /kW.
3. Ventilation – Using the same ventilation rate, the heating load from ventilation is 20 /kW.
4. Envelope Losses – Calculated as 30 /kW.
5. Total Heating Load – 250 /kW (solar) + 60 /kW (internal) + 20 /kW (ventilation) + 30 /kW (envelope) = 360 /kW.

System Sizing

Based on the calculated loads, an HVAC system with a 650 kW cooling capacity and a 380 kW heating capacity would be appropriate. The manual also recommends adding a 10–15% safety margin for equipment efficiency and future occupancy changes.

Frequently Asked Questions

Baca Juga (Artikel Terkait)

- **advanced engineering electromagnetics solution manual edition hardcover by balanis constantine a published by wiley**
  URL: http://www.denniswildberger.com/advanced-engineering-electromagnetics-solution-manual-edition-hardcover-by-balanis-constantine-a-published-by-wiley.pdf
- **advanced engineering electromagnetics solutions manual**
  URL: http://www.denniswildberger.com/advanced-engineering-electromagnetics-solutions-manual.pdf
- **advanced engineering electromagnetics wiley 1989 grading**
  URL: http://www.denniswildberger.com/advanced-engineering-electromagnetics-wiley-1989-grading.pdf
- **advanced engineering fluid mechanics by biswas**
  URL: http://www.denniswildberger.com/advanced-engineering-fluid-mechanics-by-biswas.pdf

Tags: #ashrae #cooling #heating